




Owner's Manual



Front panel



Rear panel




An extremely versatile, warm sounding transparent overdrive. With its huge range of tonal frequencies and high sound definition the SmoG will make you notice every string's twang and every note in your chord. Furthermore, the SmoG is highly touch sensitive and dynamic responsive which makes the SmoG feel like an organic extension to your guitar. The SmoG has also been specifically designed to respond well to low frequencies, therefore it will work perfectly with bass guitars as well. As with most of our pedals, the SmoG comes with a 9V battery inside, ready to rock.

Settings




Blues overdrive



Rock'n'roll



Rock solo



Bass Boost



Crunch



Treble Boost


Changing the battery

To replace the battery following the step below:

1. loosen the screws at the base of the pedal, then remove the base of the pedal unit;
2. remove the old battery from the battery housing, and remove the snap cord connected to it;
3. connect the snap cord to the new battery, and place the battery into the housing;
4. close the pedal, insert the screws into the holes and fasten them securely.

Notes:

Can be powered by a battery or an optional AC/DC adaptor.



9-18 V DC / 20mA

The input jack also works as the power switch.

Power is turned on whenever a plug is inserted into the input jack, and is turned off when the plug is disconnected.

Keep the plug out from the jack when not in use.