



Have you always felt the lack of an extra lead channel on your amplifier?

You may definitely consider the Tempesta as a lead channel. Designed to sound and respond like a saturated valve, the Tempesta will sing beautifully on any amp.

Moving the gain control clockwise will get you from a subtle fuller sound through warm, gritty rhythms, to the most spectacular saturated valves sound, with an endless sustain. The "deep" option on the toggle switch will slightly boost your mids helping your sound to cut more easily up front.

for **GUITAR**

input

jack

output jack

gain

controls saturation

tone


controls tone, right for brighter sounds, left for darker and fat tones

volume

controls output level

true bypass

engages or disengages the effect





the "deep" toggle switch slightly increases the saturation and the presence on the medium-high frequencies, helping the sound to cut more easily up front.

Position: left: off right: on

To replace the **battery**:

- 1. loosen the screws at the base
- 2. remove the base of the pedal
- 3. replace the battery
- 4. close the pedal with the screws



Settings





